



## Reverse Handing Installation Instructions® for 7 & 9 Series Mortise Locksets

1. Remove lock body cover (3 screws).
2. Remove latch, turn over and re-insert.  
Note position of latch washer.
3. Remove hub lock arm, turn over and re-insert.
4. Replace cover and re-fasten.

